

Spectrum Control, Inc.



7608A Series Power Distribution Units (PDU's) Installation and Operation Manual

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

Table of Contents

Title	Page #
1.0 Introduction	4
2.0 Safety Information	5
3.0 Technical Specifications.....	6 - 7
4.0 Connections and Installation information.....	8 - 15
5.0 Operational Commands	16 - 21
6.0 Smart Start Jr Windows Configuration Utility.....	22 - 35
7.0 LAN Module and Communications.....	36 - 60
8.0 Maintenance and Replacement Parts	61
9.0 Warranty.....	61

List of Figures

Figure 4.1 Back Panel.....	11
Figure 4.2 Hook-up to remote PC or Laptop Computer	12
Figure 4.3 Hook-up to remote PDA.....	13
Figure 4.4 LED Descriptions	15
Figure 6.1 Control Software Setup Screen	23
Figure 6.2 Select Installation Folder	24
Figure 6.3 Software Installed Successfully	25
Figure 6.4 Connect to a PDU.....	26
Figure 6.5 Select PDU Type	27
Figure 6.6 Configure Communication Settings	28
Figure 6.7 Control and Monitoring Windows.....	29
Figure 6.8 Example of All Windows	30
Figure 6.9 Sequence and Delay Settings.....	31
Figure 6.10 Communication Settings.....	32
Figure 6.11 Alarm Settings	33
Figure 6.12 Auxiliary Settings	34
Figure 7.1 RJ45 Ethernet Connector	36
Figure 7.2 Configuration Menu Using Telnet	40
Figure 7.3 Server Configuration.....	41
Figure 7.4 Serial Channel 1 Configuration	43
Figure 7.5 Login Failure Threshold Setpoint.....	44
Figure 7.6 Communication Failure Threshold Setpoint.....	45
Figure 7.7 Web Interface Monitor Screen	47
Figure 7.8 Web Interface Login Screen	48
Figure 7.9 Unit Setup Using Web Interface.....	49
Figure 7.10 Web Interface Alert Setup.....	50

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

Figure 7.11	Web Interface External Circuit Setup Screen.....	52
Figure 7.12	Web Interface User Setup Screen	53
Figure 7.13	Web Interface Outlet Control	54
Figure 7.14	Web Interface About Screen.....	55
Figure 7.15	Web Interface Device Organizer.....	58
Figure 7.16	Device Organizer Edit Menu	59
Figure 7.17	Device Organizer Node Dialog	60
Appendix A	Network Notation and IP Addressing Basics	64-67

1.0 Introduction

The Spectrum Control Smart Start Jr. is a multifunctional AC power distribution unit sophisticatedly designed to control up to eight AC loads and monitor vital parameters. The PDU has two main configurations. The first configuration has a single input and eight outputs. The second configuration has two independent inputs and each of the inputs has four outputs associated with it. There are various current ratings available. Each input has a circuit breaker to protect the PDU and associated loads. A programmable software current limit is also available for added protection. The communication and control circuitry is protected by internal fuses. The unit can still communicate when the circuit breaker is in the tripped position.

The Smart Start Jr. is capable of monitoring line voltage and total load current as well as line frequency and external temperature. Operation/control is accomplished either manually using controls on the front panel of the unit or by several communication schemes using a remote computing device such as a laptop computer, desktop computer, palm pilot, etc.

This product complies with FCC, CE, TUV, UL60950 and IEC950 requirements.

2.0 Safety Information

This installation and operation manual contains information about the Power Distribution Unit and basic installation instructions. The person installing or integrating the PDU into an electronic system must be supplied with this manual and they must read it to become familiar with the installation precautions. Spectrum Control, Inc cannot be held liable for any damage to persons or property if the safety information in the installation and operation manual is not followed.

If the safety information is not observed, personnel could be put at risk. Only authorized personnel who have been properly trained may operate the device. There are no user serviceable parts inside and any modifications made to the unit by any organization or persons other than the factory are not permitted.

The general regulations governing the use of electricity in the country in which the device or integrated system is installed must be observed.

3.0 Technical Specifications

Input

- Power Entry Connector: IEC 320/C14
- Nominal input voltage:
 - 120VAC \pm 10% for Models with “12” in the 9th and 10th digit of the part number.
 - 230 VAC \pm 10% for Models with “24” in the 9th and 10th digit of the part number.
- Input frequency: 47 – 63 Hz
- Input current:
 - 15A, 20A or 30A* maximum per input (120VAC models)
 - 7.5A, 16A or 30A* maximum per input (230VAC models)

Outputs

- Outlet Connectors: (8) Nema 5-15R, (8) Nema 5-20R or (8) IEC 320/C13
- Load Current:
 - 15A or 20A maximum per outlet group (120VAC models)
 - 7.5A or 10A maximum per outlet group (230VAC models)

Maximum load current of all receptacles combined within an outlet group, consult factory for other current ratings.

Communication

- Telnet or WEB Browser using optional LAN module
- RS-232: front panel DB-9F or DB-9M connector
- RS-485/RS-422: rear panel RJ-11 connector
(Caution: Do not connect this jack to a telephone network.)

*Note: Single input configuration only.

Auxiliary Connections

- Two input connections to generate messages. Make or break contact between two points on connector. 28 to 16 AWG solid or stranded jumper wire.
- Two Full sets of dry contacts (c, no, nc) rated 2A max, 250VAC max. (60 watts max)
- Optional E-STOP connection. Make or break contact between two points on connector. 28 to 16 AWG solid or stranded jumper wire.
- Optional temperature sensor connection.

Environmental

- Operating temperature: 0-45°C (32-113°F)
- Operating humidity: 0-95% (non condensing)
- Operating elevation: 0-10,000 ft (0-3000m)

Physical

- Unit height: 1U, 1.75 inches (4.44cm)
- Unit width: 17.25 inches (43.8cm)
- Unit depth: 8.25 inches (20.9cm)
- Weight: approximately 8 lbs. (3.7kg)
- 19" Rack mountable or tabletop
- Finish: Black powder coat

4.0 Connections and Installation Information

4.1 Operating Environment

- Locate PDU in dry area on a bench, desktop or shelf.
- Rack Mount in equipment rack using mounting brackets. PDU may be flush with front of rack or center mounted.
- Elevated Operating Ambient—If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ratings of the product.
- Installation of the equipment should be such that the amount of airflow required for safe operation of the equipment is not compromised.
- Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.
- Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on over current protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.
- Reliable earthing of equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips). Consult the local electrical code for additional information.

4.2 Electrical Connections

4.2.1 For 120 VAC products

- Depress rocker handle of all circuit breakers to “off” position, Figure 4.2.
- Connect a 3-conductor AC line cord, Figure 4.1 Item A, to the power entry module(s) at the rear panel, Figure 4.1 Item B. Cord must be rated at least or more than the input current rating of the PDU. Power source must also be rated for appropriately and have a ground.
- Connect equipment to AC outputs, Figure 4.1 Item C. Continuous current draw for all connected units must not exceed the current rating per output group.

CAUTION:

- Power source for PDU must be properly grounded.
- Cord for PDU must be rated at least or more than the rating of the PDU.
- Total current for all connected units must not exceed the current rating per input.

4.2.2 For 230 VAC products

- Depress rocker handle of all circuit breakers to “off” position, Figure 4.2.
- Connect a 3-conductor AC line cord, Figure 4.1 Item A, to the power entry module(s) at the rear panel, Figure 4.1 Item B. Cord must be rated at least or more than the rating of the PDU. Power source must also be rated for 7.5A and have ground.
- Connect equipment to AC outputs, Figure 4.1 Item A. Continuous current draw for all connected units must not exceed the current rating per output group.

CAUTION:

- Power source for PDU must be properly grounded.
- Cord for PDU must be rated at least or more than the rating of the PUD.
- Total current for all connected units must not exceed the current rating per input.

4.3 Communication Hook Up

- For LAN communications plug into the front RJ-45 jack Figure 4.2 Item G. When connecting to a 10/100 Base-T ethernet LAN hub or router use a straight through LAN cable. Use a crossover cable if connecting the PDU directly to a PC LAN port.
- For RS-232 to PC or laptop computer use a straight through serial cable to the RS-232 (DB-9S) connector on front panel, Figure 4.2D. Connector pin-outs are shown in Figure 4.2 Item E. Palm PDA's connect directly to the DB-9P connector on the front panel, Figure 4.2F. A null modem is not required.
- RS-485/RS-422 interfacing is available at rear panel 6 position modular jack (RJ11), Figure 4.1 Item D. Caution: Do not connect this jack to a telephone network.
- Consult Factory for additional Assistance with this communication Scheme.


CAUTION:

Do not connect any cable to rear RJ11 connector unless the internal configuration of this connector is known. Damage to the Smart Start Junior or connecting computing device may occur.


4.4 Auxiliary Input and Output Connections

- Temperature probe input, isolated inputs and programmable isolated relay outputs are connected to header on rear of the unit. Figure 4.1 Item E, shows the location and designation of the connections. A pluggable mating connector with screw clamp type terminals is supplied with the unit. Pin-outs are shown in Figure 4.1 Item F.
- The temperature probe should be of a type using a TMP35, LM35 or equivalent based on a two wire current based circuit with a 881 ohm scaling resistor.
- See commands for direct relay control AFFCA, and AFFCB in Section 5 for information on setting up the programmable relays.
- See commands AFFW1 and AFFW2 for using the input signals. These signals are generated when two points on the auxiliary connector are connected or disconnected from signal ground.


Back Panel
Figure 4.1



Front Panel
Figure 4.2



Front Panel
Figure 4.3




Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

4.5 LED status guide

LED	Status	Description
Outlet Status (Green LED) 1	Off	Voltage is turned off to the outlet.
	On	Voltage is applied to the outlet
RDY (Ready) 2	Off	No power applied to the unit, rear jumper removed (EPO), or unit inoperable.
	Green	Operating normally
	Blinking	Normal communications with LAN module or RS-232 ports.
LOCAL 3	On	In local mode. Start button on front panel enabled.
REMOTE 4	On	In remote mode. External communications enabled.
CH1 (Upper left) 5	Off	No power applied to the unit, or LAN module inoperable.
	Green	Normal operation of LAN module once booted up.
	Green blinking	Normal operation of LAN module when communicating.
LNK (Upper right) 6	Off	No link or connection to a network.
	Green	Network link valid.
DIA (Lower left) 7	Off	Unit operating normally
	Red or blinking	Diagnostic failure. Contact factory for further information.
CH2 (Lower right) 8	Off	Operating normally
	Yellow or Blinking	CH2 active, consult with factory for further information.

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

Figure 4.4



Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

5.0 Operational Commands

The PDU is shipped with a factory default setting of address FF. All basic commands would begin with "AFF". If the unit address is changed to another hex number the command structure would also change. All control and configuration of the SSJR settings can be changed using the command set below. LAN module configuration can only be performed through the LAN connection. Please see section 7.0 for LAN module configuration.

The basic commands are valid only when the SSJR is in the remote mode and the user is communicating using RS-232, RS422/485 or Telnet. If a external software program is used to issue commands a delay of 10 milliseconds should be used between characters and 40 milliseconds between commands being sent should be used. If the user is typing the commands below no delays are necessary as the communication scheme can keep up with the speed of the human interface.

SSJR COMMANDS		
The following commands are based on factory default settings. All commands must be followed by a carriage return. For 1X8 units use the "A" commands, for 2X4 units use the "A" and "B" commands.		
Command	Explanation	Response
BAUD RATE		
AFFB	Returns current baud rate setting	UFFB1
AFFB0	Set baudrate to 4,800 bps	UFFB0
AFFB1	Set baudrate to 9,600 bps	UFFB1
AFFB2	Set baudrate to 19,200 bps	UFFB2
AFFB3	Set baudrate to 38,400 bps	UFFB3
	If a LAN module is present do not use this command. Use the LAN module configuration menu on telnet port 9999 menu choice 1 "Channel 1 configuration"	
EXTERNAL CONTACTS (Bot row pins 6, 7, 8) When the PDU is powered on all external contact relays are turn on.		
AFFCA	Returns the setting of the external contact configuration.	UFFCA FF
AFFCA FF	Sets external contacts to monitor undervoltage condition on channel A (see AFFUA command for setpoint details)	UFFCA FF
AFFCA DD	Sets external contacts to monitor overcurrent condition on channel A (see AFFLA command for setpoint details)	UFFCA DD
AFFCA CC	Sets external contacts to monitor overtemperature condition (see AFFK command for setpoint details)	UFFCA CC

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

AFFCA 00	Sets external contacts to the OFF position.	UFFCA 00
AFFCA 01	Sets external contacts to the ON position.	UFFCA 01
	EXTERNAL CONTACTS (Top row pins 1, 2, 3) When the PDU is powered on the external contact relays are turned on.	
AFFCB	Returns the setting of the external contact configuration.	UFFCB FF
AFFCB FF	Sets external contacts to monitor undervoltage condition on channel A (see AFFUB command for setpoint details)	UFFCB FF
AFFCB DD	Sets external contacts to monitor overcurrent condition on channel A (see AFFLB command for setpoint details)	UFFCB DD
AFFCB CC	Sets external contacts to monitor overtemperature condition (see AFF command for setpoint details)	UFFCB CC
AFFCB 00	Sets external contacts to the OFF position.	UFFCB 00
AFFCB 01	Sets external contacts to the ON position.	UFFCB 01
	SEQUENCE DELAY	
AFFD	Returns the current time delay between each outlet turning on or off in tenths of seconds .	UFFD010
AFFD050	Changes the time delay to 5 seconds between each outlet turning on or off. Valid settings are from 001 to 300.	UFFD050
	TURN OFF ALL OUTLETS	
AFFE	Turns all the outputs off at the same time	UFFE
	LINE FREQUENCY	
AFFFA	Returns the line frequency for channel "A"	UFFFA060.0 HZ
AFFFB	Returns the line frequency for channel "B"	UFFFB060.0 HZ
	TOAL LOAD CURRENT	
AFFIA	Returns the total load current for channel "A"	UFFIA12.13 Amps
AFFIB	Returns the total load current for channel "B"	UFFIB10.11 Amps
	POWER ON CURRENT LIMIT	
AFFLA	Returns the power on current limit setting for channel "A". Once the load current equals or exceeds this value the remaining outlets will not be energized. Valid range is 2.0 to 25.5 amps (14 to FF hex)	UFFLA 96
AFFLA 66	Changes the power on current limit setting for channel "A" to 12 amps. Value to be scaled by 10.0 and then converted to a hex number. 12.0 amps desired trip X 10.0 = 120 then converted to a hex number = 78	UFFLA 78
AFFLB	Returns the power on current limit setting for channel "B". Once the load current equals or exceeds this value the remaining outlets will not be energized. Valid range is 2.0 to 25.5 amps (10 to FF hex)	UFFLB 96
AFFLB 32	Changes the power on current limit setting for channel "B" to 5.0 amps. Value to be scaled by 10.0 and then converted to a hex number. 5.0 amps desired trip X 10.0 = 50 then converted to a	UFFLA 32

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

	hex number = 32	
	If the current limit is exceeded during sequencing the unit will respond with IOVER and the outlet numbers that were not turned on.	IOVER8
EPO COMMUNICATION SETTINGS		
AFFH	Returns the current EPO communication setting.	UFFH0
AFFH0	Configures the EPO setting so that when the EPO communication setting is 0, no response is issued and the ready light on the front panel is off during the EPO condition	UFFH0
AFFH1	Configures the EPO setting so that when the EPO communication setting is 1, the UFFEPO response is issued for every command received during the EPO condition	UFFH1 or UFFEPO
AFFH2	Configures the EPO setting so that user intervention is required before the unit will re-sequence back on.	UFFH2
REMOTE TEMPERATURE SETTINGS		
AFFK	Returns the current over temperature setting.	UFFK FF
AFFK 37	Changes the value of the over temperature setpoint to 37 Hex. 37 = 55 degrees C Valid range from 00 to FF hex. FF = off/sensor not connected.	UFFK 37
MASTER/SLAVE CONFIGURATION		
AFFM	Returns the master/slave setting	UFFM0
AFFM0	Changes the master/slave setting to a stand alone unit	UFFM0
AFFM1	Changes the master/slave setting to a master	UFFM1
AFFM2	Changes the master/slave setting to a slave	UFFM2
PDU ADDRESS		
AFFN	Returns the current address of the PDU	UFFNFF
AFFNAA	Changes the address of the PDU to AA. Valid range from 00 to FF hex.	UFFNAA
TURN ON OUTLETS		
AFFP	Sequences outlets 1 through 8 on in the order of the programmed start up sequence.	UFFP
AFFPA	Sequences outlets 1 through 4 on in the order of the programmed start up sequence.	UFFPA
AFFPB	Sequences outlets 5 through 8 on in the order of the programmed start up sequence.	UFFPB
SEQUENCE OFF OUTLETS		
AFFQ	Sequences the outlets off in the reverse order of the start up sequence.	UFFQ

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

AFFQA	Sequences outlets 1 through 4 off in the reverse order of the start up sequence.	UFFQA
AFFQB	Sequences outlets 5 through 8 off in the reverse order of the start up sequence.	UFFQB
	DIRECT OUTLET ACCESS	
AFFr01	Returns the status of outlet #1	UFFr01 1
AFFr01 0	Turns outlet #1 off	UFFr01 0
AFFr01 1	Turns outlet #1 on	UFFr01 1
AFFr02	Returns the status of outlet #2	UFFr02 1
AFFr02 0	Turns outlet #2 off	UFFr02 0
AFFr02 1	Turns outlet #2 on	UFFr02 1
AFFr03	Returns the status of outlet #3	UFFr03 1
AFFr03 0	Turns outlet #3 off	UFFr03 0
AFFr03 1	Turns outlet #3 on	UFFr03 1
AFFr04	Returns the status of outlet #4	UFFr04 1
AFFr04 0	Turns outlet #4 off	UFFr04 0
AFFr04 1	Turns outlet #4 on	UFFr04 1
AFFr05	Returns the status of outlet #5	UFFr05 1
AFFr05 0	Turns outlet #5 off	UFFr05 0
AFFr05 1	Turns outlet #5 on	UFFr05 1
AFFr06	Returns the status of outlet #6	UFFr06 1
AFFr06 0	Turns outlet #6 off	UFFr06 0
AFFr06 1	Turns outlet #6 on	UFFr06 1
AFFr07	Returns the status of outlet #7	UFFr07 1
AFFr07 0	Turns outlet #7 off	UFFr07 0
AFFr07 1	Turns outlet #7 on	UFFr07 1
AFFr08	Returns the status of outlet #8	UFFr08 1
AFFr08 0	Turns outlet #8 off	UFFr08 0
AFFr08 1	Turns outlet #8 on	UFFr08 1
	OUTLET STATUS	
AFFS	Returns the status of the unit. The status is displayed in HEX format. The fifth digit represents outlets 8 through 5 MSB to LSB, and the sixth digit represents outlets 4 through 1 MSB to LSB. If the outlet is on the bit representing that outlet is turned on (0 = no, 1 = yes). The seventh digit represents remote ® or local (L) mode.	UFFSFFR
AFFS00	Turns all relays off simultaneously. The last two digits of the command are in hex format and will control all 8 relays. This command is useful to control multiple relays at the same time. Any two digit hex number combination can be used between 00 to FF.	UFFS00R

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

	TEMPERATURE MEASUREMENT	
AFFt	Returns the temperature reading from the optional external temperature probe. (0 to 100 C)	UFFt 000.0 C Temp

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

OUTLET SEQUENCE CONFIGURATION		
AFFT01	Returns the value of the first outlet to turn on	UFFT01
AFFT02	Returns the value of the second outlet to turn on	UFFT02
AFFT03	Returns the value of the third outlet to turn on	UFFT03
AFFT04	Returns the value of the fourth outlet to turn on	UFFT04
AFFT05	Returns the value of the fifth outlet to turn on	UFFT05
AFFT06	Returns the value of the sixth outlet to turn on	UFFT06
AFFT07	Returns the value of the seventh outlet to turn on	UFFT07
AFFT08	Returns the value of the eighth outlet to turn on	UFFT08
AFFT01 08	Sets outlet #8 to turn on first in the programmed sequence.	UFFT01 08
AFFT02 07	Sets outlet #7 to turn on second in the programmed sequence.	UFFT02 07
AFFT03 06	Sets outlet #6 to turn on third in the programmed sequence.	UFFT03 06
AFFT04 05	Sets outlet #5 to turn on fourth in the programmed sequence.	UFFT04 05
AFFT05 04	Sets outlet #4 to turn on fifth in the programmed sequence.	UFFT05 04
AFFT06 03	Sets outlet #3 to turn on sixth in the programmed sequence.	UFFT06 03
AFFT07 02	Sets outlet #2 to turn on seventh in the programmed sequence.	UFFT07 02
AFFT08 01	Sets outlet #1 to turn on eighth in the programmed sequence.	UFFT08 01
UNDERVOLTAGE SETPOINTS		
AFFUA	Returns the current value of the "A" channel undervoltage dropout setpoint in Hex format. 5A = 90 VAC	UFFUA 5A
AFFUA D2	Changes the value of the "A" channel undervoltage dropout setpoint to D2 Hex. D2 = 210VAC Valid range from 00 to FF hex.	UFFUA D2
AFFUB	Returns the current value of the "B" channel undervoltage dropout setpoint in Hex format. 5A = 90 VAC	UFFUB 5A
AFFUB D2	Changes the value of the "B" channel undervoltage dropout setpoint to D2 Hex. D2 = 210VAC Valid range from 00 to FF hex.	UFFUB D2
SOFTWARE VERSION		
AFFv	Returns the microprocessor software version	UFFvSSJR 1X8 v3.4
LINE VOLTAGE MEASUREMENT		
AFFVA	Returns the input voltage level for channel "A"	UFFVA123.5 Volts
AFFVB	Returns the input voltage level for channel "B"	UFFVB118.5 Volts

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

REMOTE MESSAGE/WORD FUNCTION		
AFFW1	Returns the value of the #1 remote message.(FF not active, 00 active)	UFFW1 FF
AFFW1 00	Activates the #1 remote message function.	UFFW1 00
N/A	Remote message indicator word	UFFW1 01
AFFW2	Returns the value of the #2 remote message.(FF not active, 00 active)	UFFW2 FF
AFFW2 00	Activates the #2 remote message function.	UFFW2 00
N/A	Remote message indicator word	UFFW2 01
RESTORE FACTORY DEFAULTS		
AFFZ	Changes all settings back to factory default	UFFZ

Notes:

1. All initiated messages are prefixed with A_{xx}, where “A” is an ASCII upper case character (Hex code = 41). “xx” is a two-character hex code address in the range 00 to FF representing an ASCII code address range from 0 to 128. Hex address 00 is the general broadcast address to all devices.
2. All commands & responses end with an ASCII carriage return character (Hex code = 0D)
3. Any command can be aborted prior to sending a carriage return by sending a Cancel (Hex = 18), or Escape (Hex = 1B) character. The PDU will discard any previous characters, and immediately look for a valid address header.
4. PDU’s that receive messages with a correct address, but fail to recognize the specific command parameters, or have illegal command parameters, will return a response with the command that was entered followed by a “?”
5. Unit will respond to a broadcast command with address “00” only if the “Start” button is depressed while the PDU is in the remote operation mode.
6. Lowest measured temperature is 0°C. There is no indication of minus temperature.

6.0 Windows Configuration and Control Utility

The PDU management utility is designed to provide a graphical user interface to operate and control the all PDU's manufactured by Spectrum Control. It provides a single program to interface to many different PDU's.

6.1 SYSTEM REQUIREMENTS

- 32 bit Windows operating systems, including:
- Windows 95, Windows 98 and later or
- Windows NT 4.0 with service pack 3, Windows 2000 and later.
- Internet Explorer 4.0 or later.
- Video resolution of 800 x 600 in high color mode.
- 64 MB or RAM.
- One open COM port for RS232 communication.
- Windows Mouse or compatible pointing device.

Note: Windows 95 and Windows NT are trademarks of Microsoft Corporation.

6.2 PROGRAM SETUP

Follow the instructions included with the media package. The installation program will install the program and create system shortcuts in the system start menu.

To remove the program, follow the instructions from your particular operating system. These directions normally point the user to the Control Panel Add/Remove programs wizard.

NOTE: Some installations may require a reboot in order to update runtime files or controls before final installation.

Load the CD into the computer which will control the PDU using a serial interface. Launch the program by double clicking on the SETUP.EXE icon. The following window will be displayed.



Figure 6.1 Control Software Setup Screen

Click on Next to install the software. The program will then display a window where the user can select the destination directory on the computer where the software will be installed. See figure 6.2.




Figure 6.2 Select Installation Folder

Choose the folder where the software will be installed and click on the next button. The software will self install in the desired location. The installation progress will be displayed in the form of several progress bars. Once completed the following window will be displayed. See Figure 6.3.




Figure 6.3 Software Installed Successfully

Once installed the user may close the window. A Smart Start icon will have been placed on the users desktop. Click on the icon to launch the smart start control program.

6.3 WINDOW LAYOUT

The Smart Start/Smart Control PDU management software consists of a main status window and three action buttons at the top of the screen. The buttons allow the user to connect to a PDU, disconnect from a PDU and open subwindows associated with a given PDU for additional control and monitoring.

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

In Figure 6.4 the connect button is illustrated. Start by clicking on the connect button as shown.




Figure 6.4 Connect to a PDU.

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

A new window will be launched as shown in Figure 6.5. This window displays all the types of PDU's that can be controlled by the software. For the Smart Start Jr. Select the appropriate tab and then click on the "OK" button.




Figure 6.5 Select PDU type.

6.4 COMMUNICATION AND DISPLAY SETUP

The window shown in Figure 6.6 allows the user to configure the software so that it can communicate with the PDU. Information that is entered on this screen will be associated with the PDU when additional control and monitoring screen are displayed.

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

Before the software connection to the PDU can be made:

- Select the PC COM port to use (1-16).
- Select the PC COM port baud rate (4800,9600,19200,38400).
- Select the PDU address in hexadecimal (00-FF).
- Select the PDU model type (1x8, 2x4).
- Select the optional temperature sensor.

These settings can be loaded or saved to the local PC. When managing several PDU's it can be beneficial to store each unit's settings for later use.

Once the proper configuration is chose the user can click on the "Connect to PDU" button in the lower left hand of the window.




Figure 6.6 Configure Communication Settings.


Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

When the PDU is located the status line will indicate PDU FOUND. The PDU monitoring variables will be transferred to the PC for display purposes. Once the variables are loaded the PDU will be visible on the Global PDU Status window.

If the software connection is not made, verify the correct cables are being used and the correct baud rates have been selected. The user may also contact the factory for telephone support.

6.5 PROCESS WINDOW MANAGER

The process window manager allows the user to open subwindows for any given PDU. Click on the process windows manager icon on the top right of the main window.



Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

Figure 6.7 Control and Monitoring windows.

Select the desired PDU and then select any or all of the process windows for the PDU. Once the selection is made click on OK to display the windows. The windows will be placed on the main screen. They can be moved and oriented to suite the users needs.




Figure 6.8 Example of all windows

There power monitor and PDU windows are used for remote monitoring of the PDU. They display a graphical representation of the PDU and parameters that are being measured.

6.6 CONTROL WINDOW

The Control window allows the user to turn individual outlets off or on, sequence the outlets off or on, and change the PDU control settings. When using the state buttons to control the outputs the PDU will remember the state of the outlets when power is removed and then re-applied. Those outlets that were turned off will remain off. If the sequence off button is used all outlets that were in the on state prior to sequencing off will sequence back on by selecting the sequence on button or with the removal and re-application of AC input power.

6.6.1 PDU SEQUENCING PROPERTIES

The sequencing window allows the user to change the order that the outputs will sequence on and the time delay between each output turning on. The reverse order and same time delay is used during a down sequence.




Figure 6.9 Sequencing and Delay Settings

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

6.6.2 PDU COMMUNICATION SETTINGS

The communication window allows the user to change the baud rate, PDU address and master/slave configuration settings. These settings are changed in the PDU microprocessor only. For units that contain an optional LAN module any communication changes should be made from the LAN module configuration software screens.




Figure 6.10 Communication Settings

6.6.3 PDU ALARM SETTINGS

The alarm settings window allows the user to change the software undervoltage, power on current limit and temperature limit settings. The undervoltage and current limit screens are shown for a single input unit. On dual input units there are undervoltage and power on current limits for each input. Each input can have a unique setting.

After the value is chosen the user must send the setting to the PDU before exiting the screen.




Figure 6.11 Alarm Settings

6.6.4 PDU AUXILIARY SETTINGS




Figure 6.12 Auxiliary Settings

The auxiliary settings window allows the user to change the emergency power off (EPO) function, external contact trigger information, and external messaging. The EPO function is an option that is configured at the factory. If the unit is equipped with the EPO option the unit can respond differently based on the configuration setting.

When enabled and programmed to a setting of “no response” when the EPO circuit is opened all outputs are turned off and the unit will not respond to any commands. When the EPO condition is rectified the unit will automatically return back to its prior state.

When configured to “EPO Response” the unit will turn off all the outputs and a message of “UFFEPO” will be returned with any command response. Once the EPO condition is returned to normal the unit will automatically return back to its prior state.

When configured to “EPO Intervention” the unit will turn off all the outputs and a message of “UFFEPO” will be returned with any command response except “AFFH2”. Once the EPO condition is returned to normal and either the AFFH2 command is received or the front panel start button is depressed the unit will automatically return back to its prior state.

There are two sets of external contacts. Their ratings are reviewed in the features and specification section of this manual. The external contacts can be forced on or off by selecting the correct button or they can be controlled by voltage, current, or temperature. The actuation level of the parameter is set by the values programmed reviewed in the previous section “Alarm Settings”.

The unit has the capability of displaying a message based on an input on the auxiliary connector located on the rear of the PDU. If there is a change in state on either of the inputs a message of “UFFW1” or “UFFW2” if the message function is enabled. When used with the optional LAN module an actual text message can be displayed or e-mailed.

6.7 TROUBLESHOOTING PROGRAM SETUP

A common installation problem exists when the operating system will not allow the install program to update the required system files. The symptom of this problem is either an error message or a continuous reboot cycle.

Some causes could be:

- Anti-Virus software.
- You do not have computer administrator privileges.
- The Operating System is blocking or protecting the system files.

Try these steps:

- Disable any anti-Virus software.
- See your network administrator if applicable.
- Run the setup program after booting the computer in SAFE MODE

7.0 LAN Module and Communications

7.1 LAN Module Interface

The optional LAN Module provides an interface between a computer network and the power distribution unit using the front RJ-45 jack. Communications between the SSJR and a computer can take place VIA a Telnet session or web browser. The module operates at 10/100MB/sec via an Ethernet communications for both of these configurations and uses a RJ45 connector for the interface jack.

Figure 7.1: LAN Connector (RJ45)




Table 7.1: LAN Connector Pinouts

LAN Connector	
Pin	Signal
1	Tx+
2	Tx-
3	Rx+
4	None
5	None
6	Rx-
7	None
8	None

The LAN module consists of integrated hardware and a network agent software program. These components provide the ability to configure, control, and monitor aspects of multiple Smart Start Jr. units using a standard web browser. The network interface can operate using Telnet, SNMP and SMTP protocols.

The LAN module is configured at the factory to an IP Address of 192.168.1.10 and netmask of 255.255.255.0. The unit is capable of getting an IP address via DHCP or AutoIP.

7.2 LAN Module IP Address and DHCP

The unit is capable of getting an IP address via DHCP provided a DHCP server exists on the network and the IP address is set to 0.0.0.0. Upon power up of the PDU, if the IP address is set to 0.0.0.0 a DHCP server on the network will supply the LAN module with an IP address gateway address, and subnet mask. If no DHCP server exists, the LAN module red diagnostic LED will blink continuously and the screen status LED will blink five times. Please consult with the factory if IP configuration is needed when using DHCP. Please make sure that the IP address that is given to the PDU is recorded so that LAN connections can be made and the commands intended for the unit are received.

7.3 LAN Module IP Address and AutoIP

To enable AutoIP the IP address must be set to 0.0.0.0. AutoIP allows the unit to obtain an address in a network that does not have a DHCP server. AutoIP assigns a random valid address to the LAN module in the range of 169.254.x.1 to 169.254.x.254 where x is between 0 and 255. This range of IP addresses is not to be used over the internet. If a LAN module has not been configured manually and cannot find a DHCP server it automatically chooses an address from the reserved range. The LAN module then uses the Address Resolution Protocol (ARP) to send out a request asking where any node using that same address or not. If another node using the same address is found the LAN module will assign another IP address, reboot and repeats the sequence.

The purpose of AutoIP is to allow a small network of AutoIP enabled devices to be set up without any need for a DHCP server. AutoIP can be disabled by setting the IP address to 0.0.1.0.

7.4 LAN Module IP Address and ARP

If a link can be established on a network but the user cannot ping the IP address of the unit, it may be necessary to re-configure the IP address using the MAC address. The MAC address is a unique serial number given to every device that could be connected to a LAN. The MAC address is on a label on the rear of the unit. If the label has been removed please contact your IP department for additional help in identifying MAC address or IP addresses trying to connect to the network. There are software packages that can scan a network for all devices connected, then the SSJR can be connected and the software will show the attributes of the newly connected device. From this information you will be able re-define the IP address and netmask of the SSJR to the necessary settings for the application.

The ARP method is available under windows based systems. The LAN module will set its address from the first directed TCP/IP packet it receives. The MAC address of the LAN module that is being changed is needed.

In order for the ARP command to work on windows, the ARP table on the PC must have at least one IP address defined other than its own. If the ARP table is empty, the command will return an error message. Type ARP -A at the DOS prompt to verify that there is at least one entry in the ARP table.

If the local computer is the only entry, ping another IP address on the network to build a new entry in the ARP table. The IP address that you ping must be a device other than the machine on which you are issuing the ARP command. Once there is at least one additional entry in the ARP table, use the following command to ARP an IP address to the LAN module.

```
“arp -s 192.168.1.10 00-20-4A-xx-xx-xx”
```

The last string of characters is to be the MAC address of the PDU that you are trying to send the new IP address.

The next step is to open a Telnet session on port 1. The connection will quickly fail, but the LAN module will temporarily change its IP address to the one designated in the ARP command.

The final step is to open a Telnet session on port 9999 to permanently save the IP address. Using the ARP command only temporarily changes the IP address. If the LAN module is reset or powered off it will revert back to the previous setting.

7.5 Telnet Communications

Telnet is supported on port 3001 and provides a command line interface. Any of the Smart Start Jr. commands in Section 5.0 can be issued.


7.5.1 LAN Module Configuration Using a Telnet Connection

To configure the LAN Module over the network, establish a Telnet connection to port **9999**. From the Windows Start menu, click **Run** and type the following command, where x.x.x.x is the IP address and 9999 is the LAN Module's fixed network configuration port number.

`telnet x.x.x.x 9999`

Note: *Be sure to include a space between the IP address and 9999.*

The default IP Address is 192.168.1.10 so the command should look like "telnet 192.168.1.10 9999". This command will launch the configuration menu. After the first sentence appears press "ENTER" to go into the setup mode and the following menu will appear.



```
Command Prompt - telnet 192.168.1.10 9999

Smart Start Jr. Network Agent 2.0
MAC address 00204A8090FB
Software version 05.5 (040401)

Press Enter to go into Setup Mode

*** basic parameters
Hardware: Ethernet TPI
IP addr 192.168.1.10, no gateway set

Application version 2.02.002

***** Channel 1 *****
Baudrate 09600, I/F Mode 4C, Flow 00

***** Channel 2 *****
Baudrate 09600, I/F Mode 4C, Flow 00

Change Setup : 0 Server configuration
                1 Channel 1 configuration
                2 Channel 2 configuration
                3 Restore default password
                4 Login failure threshold
                5 Comm failure threshold
                6 Set SmartStart Jr. and agent defaults
                7 Set CoBox factory defaults
                10 Logging port
                11 Logging enabled
                88 Exit without save
                99 Save and exit


Your choice ? _
```

Figure 7.2 Configuration Menu Using Telnet

You can configure the parameters by entering one of the numbers on the Change Setup Menu, or you can confirm default values by pressing Enter. Be sure to store the new configurations when you are finished.

7.5.2 Server Configuration

Select **0** to configure the LAN Module's basic parameters.



```
Command Prompt - telnet 192.168.1.10 9999
Change Setup : 0 Server configuration
               1 Channel 1 configuration
               2 Channel 2 configuration
               3 Restore default password
               4 Login failure threshold
               5 Comm failure threshold
               6 Set SmartStart Jr. and agent defaults
               7 Set CoBox factory defaults
               10 Logging port
               11 Logging enabled
               88 Exit without save
               99 Save and exit
               Your choice ? 0
IP Address : (192) .(168) .(001) .(010)
Set Gateway IP Address (N) N
Netmask: Number of Bits for Host Part (0=default) (0)
Change telnet config password (N) _
```

7.3 Server Configuration

7.5.2.0 IP Address

The IP address must be set to a unique value in your network. Type in the new IP address at the prompt. You may type a “.” between the number groups or press “Enter”. See Appendix A for more information about IP Addressing and network configuration.

Note: *The LAN Module cannot connect to the network if the assigned IP address is already in use by another device.*

7.5.2.1 Gateway Address

The gateway address, or router, allows communication to other LAN segments. The gateway address should be the IP address of the router connected to the same LAN segment as the LAN

Module. If a router is not present in the network or if a crossover cable is being used then it is recommended to program the IP address of the computer which will be controlling the PDU in the gateway address.

Note: *The gateway address must be within the local network.*

7.5.2.2 Subnet Mask

A netmask defines the number of bits taken from the IP address that are assigned for the host section.

Note: *Class A: 24 bits; Class B; 16 bits; Class C: 8 bits.*

The LAN Module prompts for the number of host bits to be entered, then calculates the netmask, which is displayed in standard decimal-dot notation when the saved parameters are displayed (for example, 255.255.255.0).

7.5.2.4 Telnet Configuration Password

Setting the Telnet configuration password prevents unauthorized access of the setup menu via a Telnet connection to port 9999. The password is limited to 4 characters. Option 0 allows the user to change the IP address, enter the Gateway IP address, configure the netmask and change the telnet configuration password.

```
Command Prompt - telnet 192.168.1.10 9999

Change Setup : 0 Server configuration
                1 Channel 1 configuration
                2 Channel 2 configuration
                3 Restore default password
                4 Login failure threshold
                5 Comm failure threshold
                6 Set SmartStart Jr. and agent defaults
                7 Set CoBox factory defaults
                10 Logging port
                11 Logging enabled
                88 Exit without save
                99 Save and exit
Your choice ? 1

Baudrate (09600)
I/F Mode (4C) ?
Flow (00) ?
```

Figure 7.4 Serial Channel 1 Configuration

7.5.3 Channel 1 Configuration

Channel 1 configuration is a menu option to re-configure the RS-232 serial communications. The factory defaults of 9600 baudrate, I/F mode 4C, and Flow 00 represent the scheme used on the serial channel between the LAN module and the internal microprocessor. These same settings apply to the front RS-232 D-sub connectors. If a new baudrate is desired for RS-232 communications it is necessary to make the change using this menu. Do not make changes using the low level baudrate command in section 5.0 if a LAN module is present.

7.5.4 Channel 2 Configuration


Menu option 2 is not used on this product. Changing parameters in this menu option has no effect on the product.

7.5.5 Restore Default Password

Menu option 3 automatically restores the default factory user “ssjr” and password “ssjr”. Please note that the default user and password are all in lower case.

7.5.6 Login Failure Threshold

Menu option 4 sets the threshold for the number of unsuccessful logins before the ability to login is disabled. Each time that a user attempts to log into the PDU an entry is made in a software table. If the user has “X” number of consecutive unsuccessful logins the ability to login will be disabled. The only ways to reset the login counter is to power off the PDU or increase the login failure threshold above the current number of login failures. Valid settings are from 2 to 16959.




```
Command Prompt - telnet 192.168.1.10 9999
Application version 2.02.002
***** Channel 1 *****
Baudrate 09600, I/F Mode 4C, Flow 00
***** Channel 2 *****
Baudrate 09600, I/F Mode 4C, Flow 00

Change Setup : 0 Server configuration
                1 Channel 1 configuration
                2 Channel 2 configuration
                3 Restore default password
                4 Login failure threshold
                5 Comm failure threshold
                6 Set SmartStart Jr. and agent defaults
                7 Set CoBox factory defaults
                10 Logging port
                11 Logging enabled
                88 Exit without save
                99 Save and exit
                Your choice ? 4
Login failure threshold (3):
```

Figure 7.5 Login Failure Threshold Setpoint

7.5.7 Communication Failure Threshold

Menu option 5 sets the threshold for the number of communication failures within the PDU before an alert is broadcasted. If the LAN module and internal PDU microprocessor stop communicating or become out of synchronization an entry is made in a software table. Once the number of communication errors exceeds the setpoint a SNMP alert is sent notifying the user or administrator of a communication error and that unit will need to be serviced or replaced. The entries in the software table are cumulative as long as the PDU is powered on. Upon power down the software table is reset. Valid settings are from 2 to 16959.



```
Command Prompt - telnet 192.168.1.10 9999
Application version 2.02.002

***** Channel 1 *****
Baudrate 09600, I/F Mode 4C, Flow 00

***** Channel 2 *****
Baudrate 09600, I/F Mode 4C, Flow 00

Change Setup : 0 Server configuration
                1 Channel 1 configuration
                2 Channel 2 configuration
                3 Restore default password
                4 Login failure threshold
                5 Comm failure threshold
                6 Set SmartStart Jr. and agent defaults
                7 Set CoBox factory defaults
                10 Logging port
                11 Logging enabled
                88 Exit without save
                99 Save and exit
Comm failure threshold (9):          Your choice ? 5
```

Figure 7.6 Communication Failure Threshold Setpoint

7.5.8 Set SSJR and LAN Module to Factory Defaults

Menu option 6 restores all PDU and LAN module defaults back to the factory settings. This command will ensure that both the LAN module and internal PDU microprocessor are returned to identical communication

settings. If changes are made using the commands in section 5.0 and the Smart Start Jr. PDU is no longer communicating use this menu selection to resort internal communications. PDU with LAN modules should have all configuration changes made using the LAN module configuration menu selections.

7.5.9 Set LAN Module to Factory Defaults

Select **7** to restores all factory settings in the LAN module LAN Module to the factory default settings. The server configurations remain unchanged.

7.5.10 Set LAN Module Logging Port

Select **10** to select the command logging port. When enabled the command logging feature will log the last commands received and processed by the PDU. The feature is used for security and troubleshooting purposes.

7.5.11 Enable Command Logging

Select **11** to enable logging of commands received and processed by the PDU. The commands will be displayed on the port selected by menu option 10. The feature is used for security and troubleshooting purposes.

7.5.12 Exit Configuration Mode

Select **88** exit the configuration mode without saving any changes, or select **99** to exit and save all changes. All values are stored in nonvolatile RAM. The LAN Module will automatically reset but the state of the PDU outputs will not be affected.

7.6 WEB Interface

Remote users can monitor and control the Smart Start Jr. with a standard web browser. When the Smart Start Jr.'s "home page" is requested, the browser receives a web page containing an embedded Java applet. The applet establishes a connection with the agent and provides a user interface for monitoring and controlling the Smart Start Jr. Due to the amount of graphics and LAN connection

speeds within a network the initial page could take several seconds to display.

7.7 Monitor Screen

The device applet initially displays the following screen. Please note that this screen is slightly different for 1x8 vs. 2x4 models. The LAN module software reads its configuration from the PDU microprocessor and automatically displays the proper format for the application.




Figure 7.7 Web Interface Monitor Screen

The monitor screen contains the following items:

Item	Function
Unit Name	User-defined descriptive name of the unit.
PDU Address	Number between 0-255, identifies the Smart Start Jr.
Firmware Version	Version of the basic firmware running in the Smart Start Jr.
Agent Version	Version of the agent firmware running in the embedded LAN Module
Configuration	Standalone, Master, or Slave
Unit Mode	Remote or Local
Temperature	Displays the Celsius temperature of units equipped with a temperature sensor
Voltage	Input line voltage (separate channels shown on 2x4 units)
Current	Input line current (separate channels shown on 2x4 units)
Frequency	Input line frequency (separate channels shown on 2x4 units)

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

Outlet Status Indicators	The on/off status of each outlet is shown by a green/red indicator, respectively.
Login Button	Allow the user to log into the unit to perform maintenance and control functions.
Unit Setup Button	Allows privileged users to set up and maintain basic unit information.
Alert Setup Button	Allows privileged users to set up and maintain alerts.
Circuit Setup Button	Allows privileged users to set up and maintain auxiliary circuit configuration.
User Setup Button	Allows privileged users to set up and maintain additional users.
Outlet Control Button	Allows privileged users to directly control outlets.
About Button	Displays identifying information about the applet.

7.7.1 LOGIN

The Login dialog box requests a username and password. Each username has an associated set of privileges. Initially a single username and password are defined, "ssjr" and "ssjr", respectively. This username has full privileges to set up, maintain, and control the unit. Additional users can be set up via the User Setup dialog, described below.



Figure 7.8 Web Interface Login Screen

When a username and password are entered, the applet changes the enabled/disabled status of buttons throughout the applet to reflect the users' privileges.

7.7.2 Setup

The unit setup dialog is used to set up and maintain basic operational parameters of the Smart Start Jr. and the network agent.

The screenshot shows a 'Unit Setup' dialog box with the following fields and values:

Field	Value
Unit Name	Smart Start JR. Fairview Operation
Outlet 1 Name	Email Server #1
Outlet 2 Name	Router #2
Outlet 3 Name	Email Server #1 back
Outlet 4 Name	Wireless Access Hub
Outlet 5 Name	Storage Area Ntwk
Outlet 6 Name	Data Server 1
Outlet 7 Name	Data Server 2
Outlet 8 Name	Email Server Pitt
Group 1 Name	Email Server #1
Group 2 Name	Hub and Storage
Group 3 Name	Data Servers 1,2
Group 4 Name	All E-mail servers
PDU Address	255
Master/Slave	Standalone
Baud Rate	9600 bps
Current Limit	12.0
Undervoltage Setpoint	90
Sequence Delay (sec)	1.0
Sequence	12345678
Group 1 Outlets	1300
Group 2 Outlets	4500
Group 3 Outlets	6780
Group 4 Outlets	1348

Buttons: OK, Cancel

Figure 7.9 Unit Setup using Web Interface

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

The Unit Setup dialog contains the following items:

Item	Function
Unit Name	User-defined descriptive name of the unit.
PDU Address	Number between 0-255, identifies the Smart Start Jr.
Master/Slave	Configures the unit for standalone, master, or slave operation.
Baud Rate	Baud rate of the serial Smart Start Jr, serial interface.
Current Limit A	Shown as "Current Limit" on 1x8 units – indicates the maximum allowable current draw for channel A, expressed in Amps.
Current Limit B	Not shown on 1x8 units – indicates the maximum allowable current draw for channel B, expressed in Amps.
Undervoltage Setpoint A	Shown as "Undervoltage Setpoint" on 1x8 units – indicates the minimum allowable input voltage for channel A, expressed in Volts.
Undervoltage Setpoint B	Not shown on 1x8 units – indicates the minimum allowable input voltage for channel A, expressed in Volts.
Sequence Delay	The delay between outlets when turning on or off sequentially, expressed in seconds.
Sequence	The sequence in which outlets are turned on or off automatically. If an outlet number is not entered in the sequence the outlet will remain at it's current state (on or off) until power is removed from the unit.
Outlet Names	Identifying names for each outlet. These names are displayed in the Outlet Control dialog window.
Group Names	Identifying names for outlet groupings. These names are displayed in the Outlet Control dialog window.
Group Outlets	Specify the outlet number associated with the given outlet grouping. Up to four outlets can be turned on or off simultaneously.

7.7.3 Alert Setup

The Alert Setup dialog lets the user set up and maintain conditions that cause alerts, recipients who receive alerts, and other information related to alerts.

The screenshot shows the 'Alert Setup' dialog box with the following details:

- Alert Parameters:** Voltage High Alert (V): 100.0; Voltage Low Alert (V): 90.0; Current Alert (A): 1.00; Temp Alert (°C): 65.0; Ping Interval (sec): 10; Ping Timeout (ms): 1000; Ping Threshold: 2.
- Host Configuration:** Host 1 is checked with IP 192.168.1.133. Hosts 2-8 are unchecked with IP 0.0.0.0. Each host has a 'Test' button and a 'Restart Delay (sec)' field set to 180.
- Recipients:** E-mail Recipients: roadie@specdomain.com (with Test button). Trap Recipients: 192.168.1.195, 192.168.1.100, and 0.0.0.0 (each with Test button).
- SMTP Settings:** SMTP Server: 192.168.1.1; E-mail Host ID: admin@specdomain.com; From Address: 192.168.1.10.
- Buttons:** OK and Cancel buttons at the bottom right.

Figure 7.10 Web Interface Alert Setup

Alerts and related actions can be set up for the following events:

- High input voltage
- Low input voltage
- High current draw
- High temperature
- Monitored host not detected

The Alert Setup dialog contains the following items:

Item	Function
Voltage High Alert	Input voltage at which a high-voltage alert is issued.
Voltage Low Alert	Input voltage at which a low-voltage alert is issued.
Current Alert	Current draw at which a high-current alert is issued.
Temp Alert	Temperature at which a high-temperature alert is issued.
Ping Interval	Seconds between attempts to contact a monitored host.
Ping Time-out	Milliseconds to wait for a "ping" response from a monitored host.
Ping Threshold	Number of times a "ping" fails before an alert is issued and the outlet associated with the monitored host is turned off.
Restart Delay	Number of seconds to wait before turning on the outlet associated with a monitored host that has been turned off due to a "ping" failure.
Host 1-8	IP addresses of monitored hosts associated with outlets 1-8, respectively.
Host 1-8 check box	Check box to enable Ping feature for host.
Host Test Buttons	Pings the associated host and reports the result in a popup dialog box.
E-mail Recipients	E-mail addresses of up to three e-mail alert recipients.
E-mail Test Buttons	Sends a test e-mail to the associated e-mail recipient as a test.
Trap Recipients	IP addresses of up to three SNMP trap recipients.
SMTP server	IP address of SMTP server used to issue e-mail alerts.
E-mail Host ID	Fully qualified host name to be used in e-mail alerts (can often be ignored or set to "foo")
From Address	Return address appearing on e-mail alerts.

7.7.4 Circuit Setup

The Circuit Setup dialog lets the user set up and maintain conditions that cause alerts, recipients who receive alerts, and other information related to alerts.




Figure 7.11 Web Interface External Circuit Setup

Alerts and related actions can be set up for the following events:

- External circuit 1 opened
- External circuit 2 opened
- External contact 1 voltage/current/temperature
- External contact 2 voltage/current/temperature

The Circuit Setup dialog contains the following items:

Item	Function
Circuit 1 Active	Checkbox indicating whether external circuit 1 is being monitored.
Circuit 1 Message	Message sent with alerts when circuit 1 is opened while monitored.
Circuit 2 Active	Checkbox indicating whether external circuit 2 is being monitored.
Circuit 2 Message	Message sent with alerts when circuit 2 is opened while monitored.
External Contact 1	Select variable when external contact change state (Voltage/Current/Temperature or Manual) Values used for trigger points are based on settings in the alert setup screen. Note when 2X4 configuration is used Contact 1 is tied to Channel A.
External Contact 2	Select variable when external contact change state (Voltage/Current/Temperature or Manual) Values used for trigger points are based on settings in the alert setup screen. Note when 2X4 configuration is used Contact 2 is tied to Channel B.

7.7.5 User Setup

The User Setup Dialog allows usernames, passwords, and privileges to be set up and maintained for up to eight users. When a user logs in, the functions he or she can perform are determined by the privileges established in the User Setup Dialog. By default (on new units, for example), a single user “ssjr”, password “ssjr” is defined with full privileges. Do not use “Non standard” characters, use numbers and letters only when creating usernames and passwords.




Figure 7.12 WEB User Setup Screen

The User Setup dialog contains the following items for each defined user:

Item	Function
Username	Case-sensitive user name.
Password	Case-sensitive password.
Outlet Control Privileges 1-8	If checked, the user may turn the specified outlet on or off, including sequenced operations.
Group Setup Privilege	If checked, the user may turn the specified group on or off.
Unit Setup Privilege	If checked, the user may set up and maintain basic unit parameters
Alert Setup Privilege	If checked, the user may set up and maintain alerts.
User Setup Privilege	If checked, the user may set up and maintain users.

7.7.6 Outlet Control

The Outlet Control dialog allows direct control of the Smart Start Jr. outlets, either individually or in sequenced operations. The exact items displayed and whether they are enabled depends on the type of unit (1x8 or 2x4) and the privileges of the currently logged-in user. If an outlet is manually turned off it will not be included in the automatic or power on sequences.




Figure 7.13 Web Interface Outlet Control

The Outlet Control dialog contains the following items:

Item	Function
Outlet Names	Names of outlets as defined in the Unit Setup dialog.
Outlet On/Off Buttons	Turns the associated outlet on or off
Outlet Group Names	Names of outlet groups as defined in the Unit Setup dialog.
Outlet Group On/Off Buttons	Turns the associated outlet group on or off
On Sequential Buttons	Sequences on outlets (all outlets, channel A outlets, or channel B outlets)
Off Sequential Buttons	Sequences off outlets (all outlets, channel A outlets, or channel B outlets)
Off Simultaneous	Turns off all outlets simultaneously.

7.7.7 About

The About dialog displays identifying information about the agent software and provides Spectrum Control contact information and web/e-mail links.



Figure 7.14 Web Interface About Screen

7.8 SNMP and SMTP E-Mail Alerts

Smart Start Network Agent software includes an SNMP agent, which provides read-only and read-write access to a limited number of variables. These are defined in an SNMP MIB and are shown in the following sections.

7.8.1 SNMP Variables

The OID's shown in this table are relative to the enterprise OID 1.3.6.1.4.1.11923.

Variable	Access	Description	OID
devcLineVoltageA	read-only	Line voltage for channel A, units are Volts x 10	1.1.1.1.1.1
devcLineVoltageB	read-only	Line voltage for channel B, units are Volts x 10	1.1.1.1.1.2
devcLoadCurrentA	read-only	Total load current for channel A, units are Amps x 100	1.1.1.1.1.3
devcLoadCurrentB	read-only	Total load current for channel B, units are Amps x 100	1.1.1.1.1.4
devcLineFrequencyA	read-only	Line frequency for channel A, units are Hz x 10	1.1.1.1.1.5
devcLineFrequencyB	read-only	Line frequency for channel B, units are Hz x 10	1.1.1.1.1.6
devcTemperature	read-only	Temp reading from optional external probe, units are degrees C x 10	1.1.1.1.1.7
devcSequence	read-only	Each char position contains a digit corresponding to an outlet number	1.1.1.1.1.8
devcSequenceDelay	read-only	Time delay between each outlet turning on or off in tenths of a second	1.1.1.1.1.9

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

devcPDUAddress	read-only	PDU address (0 to 255)	1.1.1.1.1.10
devcMasterSlave	read-only	Master/slave setting): 1 = standalone, 2 = master, 3 = slave	1.1.1.1.1.11
devcSoftwareVersion	read-only	Microprocessor software version	1.1.1.1.1.12
optdBaudRate	read-only	Baud rate: 1 = 4800, 2 = 9600, 3 = 19200, 4 = 38400	1.1.1.1.2.1
optdOutletsOffSimultaneous	read-write	Turn off all outlets simultaneously	1.1.1.1.2.2
optdPowerOnCurrentLimitA	read-only	Power-on current limit for channel A, units are Amps x 10	1.1.1.1.2.3
optdPowerOnCurrentLimitB	read-only	Power-on current limit for channel B, units are Amps x 10	1.1.1.1.2.4
optdOutletsOnAll	read-write	Turns on outlets 1-8 in sequence: 1 = execute	1.1.1.1.2.5
OptdOutletsOnA	read-write	Turns on outlets 1-4 in sequence: 1 = execute	1.1.1.1.2.6
OptdOutletsOnB	read-write	Turns on outlets 5-8 in sequence: 1 = execute	1.1.1.1.2.7
OptdOutletsOffAll	read-write	Turns off outlets 1-8 in reverse sequence: 1 = execute	1.1.1.1.2.8
OptdOutletsOffA	read-write	Turns on outlets 1-4 in reverse sequence: 1 = execute	1.1.1.1.2.9
OptdOutletsOffB	read-write	Turns on outlets 5-8 in reverse sequence: 1 = execute	1.1.1.1.2.10
optdOutletDirect1	read-only	On/off status of outlet 1: 1 = off, 2 = on	1.1.1.1.2.11
optdOutletDirect2	read-only	On/off status of outlet 2: 1 = off, 2 = on	1.1.1.1.2.12
optdOutletDirect3	read-only	On/off status of outlet 3: 1 = off, 2 = on	1.1.1.1.2.13
optdOutletDirect4	read-only	On/off status of outlet 4: 1 = off, 2 = on	1.1.1.1.2.14
optdOutletDirect5	read-only	On/off status of outlet 5: 1 = off, 2 = on	1.1.1.1.2.15
optdOutletDirect6	read-only	On/off status of outlet 6: 1 = off, 2 = on	1.1.1.1.2.16
optdOutletDirect7	read-only	On/off status of outlet 7: 1 = off, 2 = on	1.1.1.1.2.17
optdOutletDirect8	read-only	On/off status of outlet 8: 1 = off, 2 = on	1.1.1.1.2.18
optdUnitMode	read-only	Unit mode is local or remote: 1 = remote, 2 = local	1.1.1.1.2.20
optdUndervoltageSetpointA	read-only	Undervoltage dropout setpoint for channel A, units are Volts	1.1.1.1.2.21
optdUndervoltageSetpointB	read-only	Undervoltage dropout setpoint for channel B, units are Volts	1.1.1.1.2.22
optdSetFactoryDefaults	read-only	Changes all settings back to factory: 1 = execute	1.1.1.1.2.23
ThrsVoltageHigh	read-only	Threshold voltage triggering overvoltage trap, units are volts x 10	1.1.1.1.3.1
ThrsVoltageLow	read-only	Threshold voltage triggering undervoltage trap, units are volts x 10	1.1.1.1.3.2
ThrsCurrentHigh	read-only	Threshold current triggering overcurrent trap, units are amps x 100	1.1.1.1.3.5
ThrsTemperatureHigh	read-only	Threshold temp triggering overtemp trap, units are degrees C x 10	1.1.1.1.3.13
ThrsLoginFail	read-only	Number of login failures triggering error	1.1.1.1.3.14
ThrsCommFail	read-only	Number of comm failures triggering error	1.1.1.1.3.15
circRemoteMessage1	read-only	Remote message 1 text	1.1.1.1.4.1
circRemoteMessage2	read-only	Remote message 2 text	1.1.1.1.4.2
circActive1	read-only	Auxiliary contact circuit 1: 1 = inactive, 2 = active	1.1.1.1.4.3
circActive2	read-only	Auxiliary contact circuit 2: 1 = inactive, 2 = active	1.1.1.1.4.4
circOpenCircuit	read-only	Circuit causing open-circuit trap: 0 = none, 1 = circuit 1, 2 = circuit 2	1.1.1.1.4.5
snmpTrapRecipient1	read-only	IP address of trap recipient 1	1.1.1.1.5.1
snmpTrapRecipient2	read-only	IP address of trap recipient 2	1.1.1.1.5.2
snmpTrapRecipient3	read-only	IP address of trap recipient 3	1.1.1.1.5.3
smtpServerAddress	read-only	IP address of SMTP server	1.1.1.1.6.1
smtpUserName	read-only	User name optionally used by some SMTP servers for authentication	1.1.1.1.6.2
smtpPassword	read-only	Password optionally used by some SMTP servers for authentication	1.1.1.1.6.3
smtpHostID	read-only	Host domain of e-mail sender	1.1.1.1.6.4
smtpFrom	read-only	E-mail address of the sender	1.1.1.1.6.5
smtpEmailRecipient1	read-only	E-mail address of recipient 1	1.1.1.1.6.6
smtpEmailRecipient2	read-only	E-mail address of recipient 2	1.1.1.1.6.7
smtpEmailRecipient3	read-only	E-mail address of recipient 3	1.1.1.1.6.8
pingHost1	read-only	IP address of host powered by outlet 1	1.1.1.1.7.1
pingHost2	read-only	IP address of host powered by outlet 2	1.1.1.1.7.2
pingHost3	read-only	IP address of host powered by outlet 3	1.1.1.1.7.3
pingHost4	read-only	IP address of host powered by outlet 4	1.1.1.1.7.4
pingHost5	read-only	IP address of host powered by outlet 5	1.1.1.1.7.5
pingHost6	read-only	IP address of host powered by outlet 6	1.1.1.1.7.6
pingHost7	read-only	IP address of host powered by outlet 7	1.1.1.1.7.7
pingHost8	read-only	IP address of host powered by outlet 8	1.1.1.1.7.8
PingInterval	read-only	Interval between pings in sec. Zero disables the ping feature	1.1.1.1.7.9
pingTimeout	read-only	Time-out in milliseconds before ping attempt fails	1.1.1.1.7.10
pingFailThreshold	read-only	Number of failed pings before device is power-cycled	1.1.1.1.7.11
pingFailedHost	read-only	Most recently failed host	1.1.1.1.7.13
pingHostEnabled1	read-only	Ping host enablement flag 1, 1 = disabled, 2 = enabled	1.1.1.1.7.14
pingHostEnabled2	read-only	Ping host enablement flag 2, 1 = disabled, 2 = enabled	1.1.1.1.7.15

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

pingHostEnabled3	read-only	Ping host enablement flag 3, 1 = disabled, 2 = enabled	1.1.1.1.7.16
pingHostEnabled4	read-only	Ping host enablement flag 4, 1 = disabled, 2 = enabled	1.1.1.1.7.17
pingHostEnabled5	read-only	Ping host enablement flag 5, 1 = disabled, 2 = enabled	1.1.1.1.7.18
pingHostEnabled6	read-only	Ping host enablement flag 6, 1 = disabled, 2 = enabled	1.1.1.1.7.19
pingHostEnabled7	read-only	Ping host enablement flag 7, 1 = disabled, 2 = enabled	1.1.1.1.7.20
pingHostEnabled8	read-only	Ping host enablement flag 8, 1 = disabled, 2 = enabled	1.1.1.1.7.21
PingRestartDelay1	read-only	Interval to wait before powering-on outlet 1 in seconds	1.1.1.1.7.22
PingRestartDelay2	read-only	Interval to wait before powering-on outlet 2 in seconds	1.1.1.1.7.23
PingRestartDelay3	read-only	Interval to wait before powering-on outlet 3 in seconds	1.1.1.1.7.24
PingRestartDelay4	read-only	Interval to wait before powering-on outlet 4 in seconds	1.1.1.1.7.25
PingRestartDelay5	read-only	Interval to wait before powering-on outlet 5 in seconds	1.1.1.1.7.26
PingRestartDelay6	read-only	Interval to wait before powering-on outlet 6 in seconds	1.1.1.1.7.27
PingRestartDelay7	read-only	Interval to wait before powering-on outlet 7 in seconds	1.1.1.1.7.28
PingRestartDelay8	read-only	Interval to wait before powering-on outlet 8 in seconds	1.1.1.1.7.29
unitName	read-only	Descriptive name of Smart Start Jr. unit	1.1.1.1.8.1
unitLoginFailCount	read-only	Login failure count	1.1.1.1.8.2
unitCommFailCount	read-only	Communication failure count	1.1.1.1.8.3

7.8.2 SNMP Traps

SNMP traps are issued if trap recipients have been specified and any of the following conditions occur:

- Line voltage A greater than or equal to high threshold
- Line voltage A less than or equal to low threshold
- Line voltage B greater than or equal to high threshold
- Line voltage B less than or equal to low threshold
- Load current A greater than or equal to high threshold
- Load current B greater than or equal to high threshold
- Temperature greater than or equal to high threshold
- Ping failure threshold exceeded for host
- Remote circuit opened
- Login failure, logins disabled
- Serial communications between the Smart Start Jr. and the LAN module failed
- Test only

7.8.3 SMTP (E-mail Alerts)

E-mails are issued if e-mail recipients have been specified and any of the following conditions occur:

- Line voltage A greater than or equal to high threshold
- Line voltage A less than or equal to low threshold
- Line voltage B greater than or equal to high threshold
- Line voltage B less than or equal to low threshold
- Load current A greater than or equal to high threshold
- Load current B greater than or equal to high threshold

Spectrum Control, Inc.
Installation and Operation Manual
27-0027-0055-00

- Temperature greater than or equal to high threshold
- Ping failure threshold exceeded for host
- Remote circuit opened
- Login failure, logins disabled
- Serial communications between the Smart Start Jr. and the LAN module failed

7.8 Device Organizer

The Device Organizer is installed separately on the user's computer and provides a way to organize and access multiple Smart Start Jr. network agents.

7.9.1 Main Screen

Devices (network enabled Smart Start Jr.s) are organized in a tree structure on the left side of the main screen. The tree contains "groups" and "devices".

Figure 7.15 Web Interface Device Organizer

Groups are identified by a handle icon, which allows the group to expanded or collapsed to show or hide the contained items. Groups can contain other groups or devices. Right-clicking an item in the tree or selecting the “Edit” menu item displays the edit menu, shown below:

7.9.2 Edit Menu



Figure 7.16 Device Organizer Edit Menu

The menu contains the following items:

Item	Function
Copy	Copies the item (and any sub-items) to the clipboard
Cut	Copies the item (and any sub-items) to the clipboard and deletes it from the tree
Paste Append	Pastes the item on the clipboard at the end of the sublist belonging to the selected item.
Paste Insert	Pastes the item on the clipboard immediately before the selected item and at the same level.
Insert	Displays the Device Node dialog and inserts the result before the selected item.
Append	Displays the Device Node dialog and appends the result to the sublist belonging to the selected item.
Delete	Remove the selected item and all sub-items.
Edit	Displays the selected item in the Device Node dialog.
Connect (same window)	Connects to the network agent identified by the selected item and displays the Device Applet in the panel on the right side of the screen.
Connect (new window)	Connects to the network agent identified by the selected item and displays the Device Applet in a new browser window.

7.9.3 Device Node Dialog

The Device Node dialog allows the user to specify detailed information about groups and devices shown in the tree.




Figure 7.17 Device Organizer Node Dialog

The Device Node dialog contains the following items:

Item	Function
Type	Specifies whether the item is a group or a device
Name	Name to be displayed on the tree
URL	For devices only, specifies the URL the to be displayed when the "Connect" item is selected.

Each Smart Start Jr. Network Agent contains a web page named "client.html", which displays the Device Applet without headings. This page should be specified as the URL in the Device Node dialog.

8.0 Maintenance and Replacement parts

There are no user serviceable parts inside the PDU. In the event there is an electronic problem the unit please contact the factory.

9.0 Warranty

Under normal use and specified operation conditions the Smart Start Jr PDU is warranted from the day of delivery for a period of one year. During this period, if the product should fail, the device can be sent back to the factory for repair or replacement at the discretion of Spectrum Control.

If the device is misused or tampered with in any way the warranty becomes invalid. SCI is not liable for any damage caused by products that have been modified or serviced by other parties.

APPENDIX A
Network Notation Basics and IP Addressing

1.0 IP Addresses

Each TCP/IP node on a network host has a unique IP address. This address provides the information needed to forward packets on the local network and across multiple networks if necessary.

IP addresses are specified as x.x.x.x, where each x is a number from 0 to 255; for example, 192.0.1.99. The LAN Module must be assigned a unique IP address to use TCP/IP network functionality.

IP addresses contain three pieces of information: the network, the subnet, and the host.

1.0.1 Network Portion

The network portion of the IP address is determined by the network type: Class A, B, or C. The most common setting for use with the SSJR PDU is Class C.

Table 1: Network Portion of IP Address

Network Class	Network Portion of Address
Class A	First byte (2 nd , 3 rd , and 4 th bytes are the host)
Class B	First 2 bytes (3 rd and 4 th bytes are the host)
Class C	First 3 bytes (4 th byte is the host)

In most network examples, the host portion of the address is set to zero.

Table 2: Available IP Addresses

Class	Reserved	Available
A	0.0.0.0 127.0.0.0	1.0.0.0 to 126.0.0.0
B	128.0.0.0 191.255.0.0	128.1.0.0 to 191.254.0.0
C	192.0.0.0 225.255.255.0	192.0.1.0 to 225.255.255.0

Consider the IP address 36.1.3.4. This address is a Class A address; therefore, the network portion of the address is 36.0.0.0 and the host portion is 1.3.4.

1.0.2 Subnet Portion

The subnet portion of the IP address represents which sub-network the address is from. Sub-networks are formed when an IP network is broken down into smaller networks using a subnet mask.

A router is required between all networks and all sub-networks. Generally, hosts can send packets directly only to hosts on their own sub-network. All packets destined for other subnets are sent to a router on the local network.

1.0.3 Host Portion

The host portion of the IP address is a unique number assigned to identify the host.

1.0.3.1 Network Address

A host address with all host bits set to 0 addresses the network as a whole (for example, in routing entries).

Figure 1: Sample Network Address

192.168.1.0

1.0.3.2 Broadcast Address

A host address with all host bits set to 1 is the broadcast address, meaning for “for every station.”

Figure 2: Sample Broadcast Address

192.168.1.25

Network and broadcast addresses must not be used as a host address; for example, 192.168.1.0 identifies the entire network, and 192.168.1.255 identifies the broadcast address.

1.0.3.3 IP Subnet Mask

An IP subnet mask divides IP address differently than the standards defined by the classes A, B, and C. An IP subnet mask defines the number of bits to be taken from the IP address as the network or host sections. The LAN Module prompts for the number of host bits to be entered and then calculates the netmask, which is displayed in standard decimal-dot notation (for example, 255.255.255.0) when saved parameters are displayed.

Table 3: Standard IP Network Netmasks

Network Class	Network Bits	Host Bits	Netmask
A	8	24	255.0.0.0
B	16	16	255.255.0.0
C	24	8	255.255.255.0

Table 4: Netmask Examples

Netmask	Host Bits
255.255.255.252	2
255.255.255.248	3
255.255.255.240	4
255.255.255.224	5
255.255.255.192	6
255.255.255.128	7
255.255.255.0	8
255.255.254.0	9
255.255.252.0	10
255.255.248.0	11
...	...
255.128.0.0	23
255.0.0.0	24

1.0.2.4 Private IP Networks and the Internet

If your network is not and will not be connected to the Internet, you may use any IP address. If your network is connected or will be connected to the Internet, or if you intend to operate the LAN Module on an intranet, you should use one

of the reserved sub-networks. Consult you network administrator with questions about IP address assignment.

1.0.2.5 Network RFCs

For more information about IP addresses, refer to the following documents, which can be located on the World Wide Web using one of the following directories or indices:

- RFC 950 Internet Standard Subnetting Procedure
- RFC 1700 Assigned Numbers
- RFC 1117 Internet Numbers
- RFC 1597 Address Allocation for Private Networks